

 Additionel information
 Document number
 Version
 Page

 rds_vwv_310_001_en
 08/2020
 1 of 4

1. Identification / recognition



The electric motor is silent. The indicator on the left of the instrument cluster (power meter) indicates whether the electric drive is switched "OFF" or "READY" for operation.

Lettering





Engine compartment




2. Immobilisation / stabilisation / lifting

Immobilize the vehicle

Apply the parking brake.



Lifting points



3. Disable direct hazards / safety regulations

Turn off the ignition (Powermeter "OFF")

Press the START-STOP button without depressing the brake pedal.





Instead of a radio key, it is also possible to use a key card or smartphone app.

Deactivate the high-voltage system




Option 1: From the engine compartment



Disconnect the 12-volt battery

Disconnect the negative pole from the body contact point.





 Additionel information
 Document number
 Version
 Page

 rds_vwv_310_001_en
 08/2020
 2 of 4



Volkswagen **ID.3** 5-door model, as of 2020



Option 2: from the passenger compartment







Option 3: From the luggage compartment







Do not touch, cut or open high-voltage components and high-voltage batteries! Wear appropriate protective equipment!

In the event of an accident in which the airbags are deployed, the high-voltage system will be automatically deactivated. The high-voltage system is de-energised approx. 20 seconds after deactivation.


Disconnect from the charging station (emergency release)





- 1. Remove the right side panel.
- 2. Locate the loop of the emergency release (without the yellow flag).
- 3. Pull the loop.

4. Access to the occupants



Glass types:

- 1 Laminated safety glass
- (2) Toughened safety glass

5. Stored energy / liquids / gases / solids













400 V

000 000







12 V

Additionel information Document number Version Page



Volkswagen **ID.3** 5-door model, as of 2020



If coolant escapes from the battery cooling system, there is a risk of a thermal reaction in the high-voltage battery.

Monitor the temperature of the high-voltage battery!



6. In case of fire















Lithium-ion batteries can become damaged or improper Use promptly or with a delay to ignite or after the Ignite fire fighting again! Wear appropriate protective equipment!



7. In case of submersion

After rescuing the vehicle from the water, deactivate the high-voltage system (see Chapter 3) and allow the water to drain. Wear appropriate protective equipment!

8. Towing / transportation / storage



Do not tow a vehicle that has been involved in an accident on its drive axles.

Deactivate the high-voltage system (see Chapter 3). Park the vehicle at a safe distance, at least 5 m, from buildings and other vehicles (quarantine area).



Lithium-ion batteries can self-ignite, or re-ignite after a fire has been extinguished.



9. Important additional information

The ID.3 has no towing eye on the rear of the vehicle.

10. Explanation of pictograms used



flammable



explosive



Acute toxicity



corrosive



Hazards to the human health



Environmental hazard



Electric vehicle



High voltage



Caution, danger



Use lots of water to extinguish the fire



Lithium-ion battery



Dangerous voltage



Use thermal Infrared camera



Remove smart key



 Additionel information
 Document number
 Version
 Page

 rds_vwv_310_001_en
 08/2020
 4 of 4